



User Definable Combo Lock *Unlocking and Re-setting a Combination*


Insert Master Key




Turn key to Right 1/4 turn
until key is vertical



Spin all three dials a full
revolution



Turn round knob 1/4 turn to
Right so that arrow stops at
12-o'clock.



Remove key.
Combination may now be
re-set.

