

MK731 DIGITAL COMBINATION LOCK

USER INSTRUCTIONS – PUBLIC MODE

- 1)** Enter new user code (4 digit). Close the locker which will now be locked.
- 2)** Enter user code. Open locker. The lock will now remain unlocked until the next 4-digit code is entered.

MK731 DIGITAL COMBINATION LOCK

USER INSTRUCTIONS – PRIVATE MODE

- 1)** To open: Enter user code
- 2)** To lock: Close door and turn knob to locked position