

Precision Locker Company

www.precisionlocker.com

Replacement: Electronic Lock (H731)

- 1) Electronic Lock (H731) as installed. (Front View)



- 2) With locker door open, use a Philip's screwdriver remove the small screw.



- 3) Remove the larger screw that retains the cam on the lock cylinder



- 4) Remove cam, then remove Large Hex Nut using 7/8" socket.



- 5) Remove the lock from the door.



- 6) Insert Replacement lock into the door and reattach using screws, nut and cam previously removed. (Note Cam orientation with door unlocked.)



7) The cam may be adjusted to ensure that it engages the locker appropriately. Maintain slight clearance between cam and locker when the door is locked. Engagement of cams must not be too snug when locked to avoid jamming lock.

